

BRINE TANK CLEANING PROCEDURE

The general procedure, for cleaning a brine tank, is as follows:

1. Allow the salt to get a few inches below the water level. This will be the time you would typically add salt to the brine tank.
2. Unplug the unit from the electrical outlet, bypass the system.
3. Disconnect the tubing that connects the salt storage tank to the main control valve.
4. Bail out the excess water and salt, left in the brine tank, and reattach the tubing that connects the brine tank to the main control valve.
5. Plug the power cord back into the electrical outlet, reset the current time of day on the main control valves timer, and put the bypass back into the service position.
6. **NOTE:**
 - a. **UNITS THAT FILL THE BRINE TANK FIRST:** Add 2-3 gallons of water to the brine tank, then fill the brine tank with salt.
 - b. **UNITS THAT FILL THE BRINE TANK AFTER A REGENERATION:** Add 5-6 gallons of water to the brine tank, then fill the brine tank with salt so that the salt covers the water.
7. The next time the system regenerates it will refill the brine tank to its proper water level. This may be higher or lower than the 2-3 or 5-6 gallon level in step 6.